

Wilsonart® Backsplash

Care & Maintenance

2501 Wilsonart Drive
P.O. Box 6110
Temple, TX 76503-6110

ROUTINE CARE

Your decision to purchase Wilsonart® Backsplash will bring you years of quality performance.

Everyday cleaning of Wilsonart Backsplash is easy with a quick wipe with a damp sponge. Warm water and a very mild soap or detergent can be used for more routine and aggressive cleaning. General household cleaners and detergents, such as Windex® and Formula 409® Glass & Surface may also be used. Rinse thoroughly with warm water and wipe dry. To avoid streaking, use a dry cloth immediately after the wet cleaning step.

Do NOT use abrasive cloths/pads or cleaners that contain abrasives, acids or alkalis, as they will mar the surface.

Ensure that the edges of your Wilsonart Backsplash are properly sealed with a 100% silicone sealant. If the silicone is removed, repair it immediately.

A FEW NOTES OF CAUTION

- Wilsonart® Backsplash is not recommended or suitable for direct application behind gas cooktops or gas slide-in ranges (without control panels). Direct contact with cookware or heat source should be avoided at all times.
- Drain cleaners containing lye will permanently damage any Wilsonart Backsplash surface. Prevent any splashing during use.
- Never allow hot pots or dishes to come in contact with backsplash surface; such extreme heat can cause melting and blistering.
- Do not work with oven cleaners on an unprotected countertop or backsplash. Wipe spills or splashes away promptly and rinse several times with water.
- Rust removers contain harsh chemicals which will quickly cause permanent damage. If a spill or splash occurs, wipe off all residues immediately, wash thoroughly with soapy water and rinse several times.
- Toilet bowl cleaners contain harsh chemicals that can cause permanent damage. If spills occur, wipe up immediately, wash surface with soapy water and rinse several times.